



# M-RDLT-BLADE HEADBOARD READING LIGHTS


## ABOVE SURFACE INSTALL GUIDE

Distributed by



Mormax Company, Inc.  
8 Westchester Plaza  
Elmsford, NY 10523

914-699-0101  
sales@mormax.com  
mormax.com



CUT HOLE IN BOTTOM

1

Rout/cut bottom of wood/stone/etc. for reading lights as indicated on template labeled "ROUTING TEMPLATE".



INSTALL READING LIGHT

2

Insert reading light from top, and slip mounting brackets as shown over threaded studs. Screw the four nuts (8-32) onto each of the four studs below the mounting brackets and tighten, locking the reading light in place.




# M-RDLT-BLADE HEADBOARD READING LIGHTS

Distributed by



Mormax Company, Inc.  
8 Westchester Plaza  
Elmsford, NY 10523

914-699-0101  
sales@mormax.com  
mormax.com



**ROUTING  
TEMPLATE**



# M-RDLT-BLADE HEADBOARD READING LIGHTS

Distributed by



Mormax Company, Inc.  
8 Westchester Plaza  
Elmsford, NY 10523

914-699-0101  
sales@mormax.com  
mormax.com

